

spacer (246×346×76 mm, {'name': 'PP Moplen HP500N', 'family': 'PP', 'shrinkag

DXF: spacer.dxf

Layers: 0 (silhouette), DIMS, TOL, SF, GDNT

Open the DXF in AutoCAD, BricsCAD, LibreCAD, or any
CAM package to view + machine the plate.